

SKID-PLATE for V-STROM 650 (instructions)

- 1) The plate uses 3 mounting points, two on the sides and one on the crash-bars. Note that you'll be using the provides bolts, discarding the replaced ones.



- 2) Remove the bolt under the brake pedal.



- 3) Remove the bolt under the gear shift level.



- 4) The metal bracket will be installed here. Insert the provided bolt.



- 5) Install the bracket in place but do not tighten the provided nut yet.



- 6) Loosen the bolt holding the crash-bars joint.



- 7) Install the bellypan on the right side using the provided bolt. Use the silicone washer on the outside and the metallic washer on the inside. Do not tighten the bolt yet.



- 8) Do the same on the left side and again do not tighten the bolts yet.



- 9) Insert the front mounting bracket in the crash-bars joint and tighten the bolt. Depending on the type of crash-bars, you might need to discard the old spacer.



10) Tighten the bolts on the left side.



11) Finally tighten the bolt on the right side.



If you have any questions, please contact us at
info@motodrift.com